



PlanetAir Turf Products, LLC  
1065 24<sup>th</sup> Avenue SW  
PO Box 625  
Owatonna, MN 55060  
877-800-8445  
email: [info@planetair.biz](mailto:info@planetair.biz)  
[www.planetair.biz](http://www.planetair.biz)

## Service Bulletin June 2004: Tine Installation



### Step#1

Back off the square head set screw two complete turns. Set an adjustable wrench to the width of the tine. With the adjustable wrench hold the tine in the tine shaft in alignment and tighten the top bolt completely. An impact wrench is preferred. Note: **This is the primary fastening mechanism for PlanetAir tines.**



### Step #2

Next, with a 3/8" hand wrench tighten the square head set screw into the back of the tine. Note: **Impact wrench will damage set screws.**



### Step #3

Last, with a 9/16" hand wrench tighten the jam nut on the set screw.

Product may be covered by U.S. Patent No. 6,513,603.  
Other US and foreign patents pending.